

LEGEND


————— FACTORY INSTALLED WIRING

NOTE

* INDICATES SUPPLIED BY CONTROL CONTRACTOR

- Secure the controller by installing the screw provided through the anti-rotation slot's bushing and o-ring.

NOTE Center the bushing in the slot. Failure to do so may cause the actuator to stick or bind.



PROJECT:

ENGINEER:

CUSTOMER:

SUBMITTAL DATE:

SPEC. SYMBOL:



SDV5000
CARRIER OPN-VAVB1
SCR REHEAT
VARIABLE OR CONSTANT VOLUME

12194

2012/03/01