

MANUAL – INSTALLATION

Linear Vane Diffuser

LV1/LV2

v100 – Issue Date: 08/29/16

© 2016 Price Industries Limited. All rights reserved.


PRICE[®]

LINEAR VANE DIFFUSER

INSTALLATION INSTRUCTIONS

Lay in Installation - ii00058


DIMENSIONAL DATA ▼



LISTED SIZE	D DUCT SIZE
3 1/2	3 5/8 (92)
4 1/4	4 3/8 (111)
5	5 1/8 (130)
5 3/4	5 7/8 (149)
6 1/2	6 5/8 (168)
8	8 1/8 (206)
9 1/2	9 5/8 (244)
11 3/4	11 7/8 (302)


STEP 1 ▼

ATTACH PLENUM TO DIFFUSER USING SELF TAPPING SCREWS (BY OTHERS). FOR CONTINUOUS RUNS, USE SPLICE PINS TO ALIGN AND ATTACH MULTIPLE SECTIONS.




STEP 2 ▼

CONNECT DUCT TO PLENUM INLET.



STEP 3 ▼

LAY IN DIFFUSER INTO CEILING GRID.




LINEAR VANE DIFFUSER

INSTALLATION INSTRUCTIONS


Surface Mount Installation - ii00058

DIMENSIONAL DATA ▼




LISTED SIZE	D DUCT SIZE
3 1/2	3 5/8 (92)
4 1/4	4 3/8 (111)
5	5 1/8 (130)
5 3/4	5 7/8 (149)
6 1/2	6 5/8 (168)
8	8 1/8 (206)
9 1/2	9 5/8 (244)
11 3/4	11 7/8 (302)


STEP 1 ▼



STEP 2 ▼




STEP 3 ▼



STEP 4 ▼

FOR CONTINUOUS RUNS, USE SPLICE PINS TO ALIGN AND ATTACH MULTIPLE SECTIONS.




LINEAR VANE DIFFUSER

INSTALLATION INSTRUCTIONS


Frame Installation - ii00058

DIMENSIONAL DATA ▼




LISTED SIZE	D DUCT SIZE
3½	3 ⁵ / ₈ (92)
4¼	4 ³ / ₈ (111)
5	5 ¹ / ₈ (130)
5¾	5 ⁷ / ₈ (149)
6½	6 ⁵ / ₈ (168)
8	8 ¹ / ₈ (206)
9½	9 ⁵ / ₈ (244)
11¾	11 ⁷ / ₈ (302)

STEP 1 ▼



STEP 2 ▼




STEP 3 ▼



STEP 4 ▼

FOR CONTINUOUS RUNS, USE SPLICE PINS TO ALIGN AND ATTACH MULTIPLE SECTIONS.



This document contains the most current product information as of this printing.
For the most up-to-date product information, please go to www.priceindustries.com.

© 2016 Price Industries Limited. All rights reserved.

price[®]