





NODE DOWNLIGHT USER MANUAL











2 Required Parts


A) Recessed Channel



B) Trimless




C) Flush Channel






All Installations






4 Mounting Scenarios


A) Recessed Channel Installation




4. Mounting Scenarios, A) Recessed Channel Installation - Continued...



4. Mounting Scenarios, A) Recessed Channel Installation - Continued...





4. Mounting Scenarios, A) Recessed Channel Installation - Continued...





4 Mounting Scenarios


B) Trimless Installation





















4. Mounting Scenarios, B) Trimless Installation - Continued...












4. Mounting Scenarios, B) Trimless Installation - Continued...











Mounting Scenarios

C) Flush Channel Installation



4. Mounting Scenarios, C) Flush Channel Installation - Continued...



4. Mounting Scenarios, C) Flush Channel Installation - Continued...

