

MANUAL - INSTALLATION

Rectangular Industrial Displacement Diffuser


DFXi Series





RECTANGULAR INDUSTRIAL DISPLACEMENT DIFFUSER


INSTALLATION INSTRUCTIONS

- 1. Place DFXi in desired location.
- 2. Locate unit to ensure that active diffuser faces point in required direction.
- 3. Connect duct to unit and seal as required.









RECTANGULAR INDUSTRIAL DISPLACEMENT DIFFUSER

NOTES	

This document contains the most current product information as of this printing. For the most up-to-date product information, please go to priceindustries.com.

 $\hfill \ensuremath{\text{@}}$ 2015 Price Industries Limited. All rights reserved.

