


MOUNTING INSTRUCTIONS

TURN THE DAMPER FULLY CLOCKWISE.
DEPRESS CLUTCH AND TURN ACTUATOR FULLY CLOCKWISE.
PLACE UNIT OVER DAMPER SHAFT AND SECURE U-BOLT.
INSERT ANTI-ROTATION SCREW LEAVING SOME PLAY IN THE UNIT.
DEPRESS THE CLUTCH AND CHECK ENTIRE ASSEMBLY FOR SMOOTH OPERATION.
ADJUST END OF SHOCK STOPS IF NECESSARY.

NOTE

CONTROLLER MUST BE MOUNTED IN AN UPRIGHT POSITION AS SHOWN.
IF ACTUATOR MUST BE MOUNTED IN OTHER THAN UPRIGHT POSITION LEAVE A LOOP IN THE FLOW SENSOR TUBING SO THAT CONDENSATION WILL NOT RUN INTO THE CONTROLLER.



NOTE :

* INDICATES COMPONENTS SUPPLIED BY CONTROL CONTRACTOR.
** WIRE HEATER STAGE AS REQUIRED

LEGEND

————— FACTORY FLOW SENSOR TUBING
————— FACTORY ELECTRICAL WIRING

PROJECT:



ENGINEER:

CUSTOMER:

16330

SUBMITTAL DATE:

SPEC. SYMBOL:

04/03/2010

**FAN POWERED
TELETROL iVAV-TSC**
Clg., HW REHEAT
OR UP TO 2 STG ELEC REHEAT
Variable & Constant Volume